


H.BENEŠOV 2-5  
2-6

H.BENEŠOV 1-5  
1-6

10,3-12,0 7



orientační měřítko = 1:6000

± 5000

TPE HVOZDNICE